



IMPORTANT

Before installation, please make sure that all accessories are ready. (As shown in the picture below).


PRODUCT INFORMATION



SCHEMATIC DIAGRAM



Assembly Completion Diagram



Installation Completion Diagram
(Lift the seat)

Customer Support



Contact us by email: service@joytutus.com







JOYTUTUS help center:
<http://support.joytutus.com>



✓ INSTALLATION TIPS






STEP 1:

Required accessories:




STEP 2:

Required accessories:





STEP 3:

Required accessories:




Select the hole position as shown in the figure for installation




STEP 4:

If the seat is not electric, this step can be ignored

Required accessories:



Mounting Location:




✓ INSTALLATION METHOD ON THE VEHICLE

METHOD 1: Non-electric seat model


Required tool: (self-provided)

External Torx Wrench




Premise: Lift the seat

STEP 1:



STEP 2:



Lower the seat and the installation is complete!

METHOD 2: Electric seat model


Required tool: (self-provided)

External Torx Wrench




Premise: Lift the seat

STEP 1:



STEP 2:



Lower the seat and the installation is complete!